

Holding Tank Rinser with Shut-off Valve

DIRECTIONS:

1. **HOOK-UP:** Connect Camco Holding Tank Rinser to extension hose.
2. **RINSE:** Empty holding tank in usual manner. Leave tank drain valve open.
3. Insert Rinser into holding tank through toilet tank, and open faucet for full flow. Use 1/4 turn rinser handle to stop/start flow if necessary while rinsing tank. **NOTE:** Do not expose unit to pressures in excess of 100 PSI. **NOTE:** Keep toilet valve depressed while using Camco Rinser. Do not allow the valve to snap back against Rinser. Some types of valves may become damaged by force of contact.
4. Flush, slowly turning Rinser to reach all sides of tank using cold or hot water.
5. **STORE:** Close faucet and open 1/4 shut-off valve to drain water from hose and Rinser.


IMPORTANT:

Because the Camco Rinser is used inside the high bacteria area of the holding tank, always clean Rinser thoroughly in strong solution of chlorine bleach before storing.

GENERAL INFORMATION:

Usually you will need to use your Camco Rinser only at the end of a trip or when your RV will not be used again for a few days. Normal tank emptying during a trip does not require additional flushing with fresh water except under unusual conditions.

Tanks should be emptied and flushed out immediately after use. Should tank be allowed to dry out, fill with water and allow to stand and soak for several hours. When waste liquefies, dump tank and flush with Camco Rinser.



Rinceuse de bac à eaux usées Avec soupape d'arrêt

MODE D'EMPLOI :

1. **RACCORDEMENT :** Raccorder la rinceuse de bac à eaux usées Camco au tuyau-rallonge.
2. **RINCER :** Vider le bac à eaux usées de la façon habituelle. Laisser la soupape de purge du bac ouverte.
3. Insérer la rinceuse dans le bac par la cuvette de réservoir de la toilette et ouvrir le robinet pour rincer à fond. Utiliser la poignée quart de tour de la rinceuse pour arrêter ou amorcer écoulement, si nécessaire, pendant le rinçage du bac. **NOTA:** Ne pas exposer la rinceuse à une pression de plus de 689,5 kPa (100 lb/po²). **NOTA :** Garder la soupape de la toilette abaissée pendant l'utilisation de la rinceuse. Empêcher la soupape de se refermer sur la rinceuse. Certains types de soupape se brisent à force d'entrer en contact trop souvent avec la rinceuse.
4. Rincer en tournant la rinceuse lentement pour atteindre tous les côtés du bac avec de l'eau chaude ou froide.
5. **RANGEMENT :** Fermer le robinet et ouvrir la soupape d'arrêt d'un quart de tour pour laisser s'écouler l'eau du tuyau et de la rinceuse.

IMPORTANT :

Vu que la rinceuse Camco est utilisée à l'intérieur de la zone du bac hautement contaminée de bactéries, il faut toujours la nettoyer à fond dans une forte solution chlorée à blanchir avant de la ranger.

GÉNÉRALITÉS :

Ordinairement, il suffit d'utiliser la rinceuse Camco à la fin d'un voyage ou lorsque le VR ne sera pas utilisé pendant quelques jours. La vidange normale du bac au cours d'un voyage n'exige pas un rinçage supplémentaire à l'eau propre, sauf dans des circonstances exceptionnelles. Les bacs devraient être vidés et rincés immédiatement après l'usage. Si le bac vient à sécher, le remplir d'eau et le laisser tremper pendant plusieurs heures. Lorsque les dépôts deviennent liquides, vider le bac et le rincer avec la rinceuse Camco.



121 Landmark Dr./ Greensboro, NC 27409
1-800-334-2004/ www.camco.net